



Replacement Parts List

PARTS & SERVICE DEPARTMENT

Nashville, Tennessee

615-889-8900 • Fax: 615-882-2918

parts_team@lochinvar.com


www.Lochinvar.com

SHIELD™

Water Heater


SNR126-065, 151-100, 201-100

SNA151-100, 201-100, 286-125, 401-125, 501-125




IMG00507


CONTROL PANEL ASSEMBLY SNR/A 126 - 201




CONTROL PANEL ASSEMBLY SNR/A 286 - 501




GAS TRAIN ASSEMBLY SNR/A 126 - 286




GAS TRAIN ASSEMBLY SNR/A 401



HEAT EXCHANGER ASSEMBLY



GAS TRAIN ASSEMBLY SNR/A 501



ITEM NO.	PART NO.	DESCRIPTION	MODEL
HEAT EXCHANGERS			
1	100276500	HEAT EXCHANGER	SNR126-065
1	100276580	HEAT EXCHANGER	SNR/A151-100
1	100276591	HEAT EXCHANGER	SNR/A201-100
1	100276592	HEAT EXCHANGER	SNA286-125
1	100276594	HEAT EXCHANGER	SNA401-125
1	100276595	HEAT EXCHANGER	SNA501-125
CONTROLS			
2	100167623	CONNECTION BOARD	ALL
3	100167865	INTEGRATED CONTROL	SNR126, SNR/A151 & 201
3	100167866	INTEGRATED CONTROL	SNA401
3	100167867	INTEGRATED CONTROL	SNA286 & 501
3	100167868	HIGH ALTITUDE INTEGRATED CONTROL	SNR126, SNR/A151 & 201
3	100167869	HIGH ALTITUDE INTEGRATED CONTROL	SNA401
3	100167870	HIGH ALTITUDE INTEGRATED CONTROL	SNA286 & 501
4	100167627	USER INTERFACE CONTROL	ALL
5	100208509	PUMP RELAY	ALL
6	100208565	WATER TEMP SENSOR, INLET	ALL
7	100208566	OUTLET SENSOR/ HIGHT LIMIT	ALL
8	100145003	FAN ASSEMBLY	SNR126
8	100145004	FAN ASSEMBLY	SNR/A151
8	100145005	FAN ASSEMBLY	SNR/A201
8	100145006	FAN ASSEMBLY	SNA286
8	100145008	FAN ASSEMBLY	SNA401
8	100144984	FAN ASSEMBLY	SNA501
9	100208764	GASKET / BLOWER	SNR151
9	100208101	GASKET / BLOWER	SNR126, SNR/A201-401
9	100208759	GASKET / BLOWER	SNA501
10	100208381	PRESSURE SWITCH	SNR126, SNR/A151
10	100166111	PRESSURE SWITCH	SNR/A201
10	100166099	PRESSURE SWITCH	SNA286
10	100208378	PRESSURE SWITCH	SNA401
10	100166116	PRESSURE SWITCH	SNA501
GAS VALVES			
11	100171985	GAS VALVE ASSEMBLY	SNR126
11	100171986	GAS VALVE ASSEMBLY	SNR/A151
11	100171987	GAS VALVE ASSEMBLY	SNR/A201
11	100171988	GAS VALVE ASSEMBLY	SNA286
11	100171989	GAS VALVE ASSEMBLY	SNA401
11	100171990	GAS VALVE ASSEMBLY, NAT	SNA501
11	100171991	GAS VALVE ASSEMBLY, LP	SLA501
12	100208324	GAS VALVE ON/OFF SWITCH	SNR126, SNR/A151, 201 & SNA286
13	100208760	GAS VALVE GASKET	SNR126, SNR/A151 & 201, SNA286
13	100208761	GAS VALVE GASKET	SNA401
14	100146149	GAS CUT OFF VALVE 1X1	SNA401-501
15	100163233	AIR INLET KIT	SNR126 & SNR/A201
15	100163234	AIR INLET KIT	SNR/A151
15	100163235	AIR INLET KIT	SNA286
15	100163236	AIR INLET KIT	SNA401
15	100163237	AIR INLET KIT	SNA501
PILOT & BURNER ASSEMBLIES			
16	100165930	FLAME SENSOR W/ GASKET	ALL
17	100208091	FLAME SENSOR GASKET	ALL
18	100165929	IGNITOR W/ GASKET	ALL
19	100208086	IGNITOR GASKET	ALL
20	100135278	BURNER W/ GASKET	SNR126
20	100135308	BURNER W/ GASKET	SNR/A151
20	100135309	BURNER W/ GASKET	SNR/A201
20	100135310	BURNER W/ GASKET	SNA286
20	100135311	BURNER W/ GASKET	SNA401-501
21	100208085	BURNER GASKET	ALL
22	100173796	GAS/AIR ARM ASSEMBLY W/ GASKET	SNR126
22	100173791	GAS/AIR ARM ASSEMBLY W/ GASKET	SNR/A151
PLEASE HAVE SERIAL NUMBER WHEN ORDERING PARTS			

ITEM NO.	PART NO.	DESCRIPTION	MODEL
PILOT & BURNER ASSEMBLIES (CONTINUED)			
22	100173792	GAS/AIR ARM ASSEMBLY W/ GASKET	SNR/A201, SNA286-401
22	100173793	GAS/AIR ARM ASSEMBLY W/ GASKET	SNA501
23	100173749	HEAT EXCHANGER ACCESS DOOR KIT	ALL
24	100094572	HEX DOOR TEMP SWITCH BEGINNING SERIAL #F14	SNA286-501
MISCELLANEOUS			
25	100163249	SIGHT GLASS W/ GASKET	ALL
26	100208762	SIGHT GLASS GASKET	ALL
27	100145602	INSULATION, BURNER PLATE DOOR	ALL
28	100208061	INSULATION BAFFLE, DIVIDER PLATE	ALL
29	100162509	DISPLAY BEZEL LOWER	ALL
30	100189211	DISPLAY BEZEL UPPER	SNR126, SNR/A151 & 201
30	100189212	DISPLAY BEZEL UPPER	SNA286-501
31	100208446	T & P RELIEF 150#	SNR126
31	100167359	T & P RELIEF 150#	SNR/A151 & 201
31	100167403	T & P RELIEF 150#	SNA286-501
32	100208315	CONDENSATE TRAP	ALL
33	100208243	BLOCKED DRAIN SWITCH	ALL
34	100208556	FLUE TEMP SENSOR KIT	SNR126, SNR/A151 & 201
34	100170642	FLUE TEMP SENSOR KIT	SNA286-501
35	100208088	GASKET, DOOR RUBBER	ALL
36	100208107	GASKET, DOOR ROPE	ALL
37	100166586	FLUE COLLAR	SNR126, SNR/A151 & 201
37	100189054	KIT, FLUE COLLAR 4"	SNA286-501
38	100208654	ANODE ROD, MAGNESIUM	ALL
39	100208230	TRANSFORMER	ALL
40	100208552	TANK SENSOR	ALL
-	100233695	BULB WELL	ALL
41	100163033	SEAL, KNOCK OUT	ALL
42	100208330	SEAL, KNOCK OUT 2 1/2"	ALL
43	100141595	VALVE, DRAIN BRASS	ALL
44	100233625	COPPER TUBE GASKET	SNR126, SNR/A151 & 201
44	100146372	COPPER TUBE GASKET	SNA286
44	100146373	COPPER TUBE GASKET	SNA401-501
-	100208807	FUSE, 1.25 AMP	ALL
-	100208231	FUSE, 3.15 AMP	ALL
-	100208232	FUSE, 5 AMP	ALL
-	100208652	MRLWCO WITH TEST	ALL
-	100157721	NEUTRALIZER KIT	ALL
-	100148402	LIMIT, HEAT EXCHANGER OVER TEMP	SNA286-501
-	100172915	HARNESS, UNIT	SNR126, SNR/A151 & 201
-	100072938	HARNESS, UNIT	SNA286-501
-	100172916	HARNESS, POWER	SNR126, SNR/A151 & 201
-	100172933	HARNESS, POWER	SNA286-501
-	100172774	CORD, POWER	ALL
-	100172936	HARNESS, CONNECTION BOARD	SNR126, SNR/A151 & 201
-	100172945	HARNESS, CONNECTION BOARD	SNA286-501
-	100208620	HARNESS, ELECTRODE SPARK	ALL
-	100208622	HARNESS, ELECTRODE, FLAME SENSOR	ALL
-	100208636	CABLE, RIBBON	SNR126, SNR/A151 & 201
-	100208638	CABLE, RIBBON	SNA286-501
-	100173091	HARNESS, GAS VALVE	SNA401
-	100173314	HARNESS, GAS VALVE	SNA501
-	100159008	LP CONVERSION KIT	SNR126, SNR/A151
-	100159009	LP CONVERSION KIT	SNR/A201
-	100159010	LP CONVERSION KIT	SNA286
-	100159011	LP CONVERSION KIT	SNA401
PUMPS			
45	100208410	PUMP W/ HARDWARE	SNR125, SNR/A151 & 201
45	100166384	PUMP W/ HARDWARE	SNA286
45	100166374	PUMP W/ HARDWARE	SNA401 & 501
JACKET ASSEMBLY			
46	100149767	JACKET, OUTER, TOP, FRONT	SNR126, SNR/A151 & 201
46	100149768	JACKET, OUTER, TOP, FRONT	SNA286-501
47	100149769	JACKET, OUTER, UPPER, REAR	SNR126, SNR/A151 & 201
47	100149770	JACKET, OUTER, UPPER, REAR	SNA286-501
48	100149771	JACKET, OUTER, UPPER, SIDE	SNR126, SNR/A151 & 201
48	100149772	JACKET, OUTER, UPPER, SIDE	SNA286-501
PLEASE HAVE SERIAL NUMBER WHEN ORDERING PARTS			